







The PlungerTM Orifice eliminates costly down time because of a plugged orifice. No need to remove the Plunger' Orifice from tip, simply insert hex wrench into the orifice and push upward forcing the spring loaded PlungerTM to remove any plugging debris. Its easy and quick, in seconds you're back in operation!